

# **SINGER**

## **112W131**

Form 2731w

( 741 )

Printed in U. S. A.




# SINGER

112w131




THE SINGER MANUFACTURING COMPANY




Copyright, U. S. A., 1939, 1940 and 1941  
by The Singer Manufacturing Co.  
All Rights Reserved for all Countries


13067 - 1/2




259143




224140



16261 - 1/2




16615 - 1/2




16643 - 3/8


228368




16644 - 1/3



17751 - 3/8




17762 - 1/3




17763 - 3/8

236831




17764 - 3/8







17765




17766




17767 - 2/3




17768 - 2/3




17769 - 1/3




17770 -  $\frac{3}{8}$



17771 - 2/3




17772 - 1/3




17773 - 3/4


236923-46  
236924-50 1/2 17/32 1/16 19/32 5/8  
200161D




236925-46




236926-46




236929-46  
236930-50




236907




236909



236908




236910




17774 - 3/4


236922-50  
13/32 7/16 15/32 1/2




236906



236918-46  
17/32 9/16  
236916-46  
19/32 5/8 21/32 11/16



236915-46  
23/32 3/4  
236917-46  
25/32 13/16 27/32 7/8 29/32 15/16 31/32 1



236914-46  
13/32 7/16 15/32 1/2 17/32 9/16

